we-ef



WE-EF LEUCHTEN

Installation and Maintenance
Instructions

Post Top Luminaire
ASP530 LFD



Do not open during installation

This product is factory-sealed. Refer to the instructions contained in this document for details.



Surge Protection


This product features built-in surge protection circuitry in compliance with applicable standards.

For comprehensive protection of a luminaire installation against lightning and electrical surges, it is essential to cover mains supply and data input lines at the distribution board level, by using respective primary (Type 1) and secondary (Type 2) surge arrestors in compliance with EN61643-11/IEC61643-1.

Warning

Ensure that all required surge protection measures are in place and activated prior to luminaire installation. Also, disconnect luminaires before operating high-power devices such as, for example, electrical arc welders.

Post Top Luminaire



IP66, Class I, ta ≤ 40°C

Light Source

LFD

Maintenance

Apart from cleaning the product's exterior surfaces, no special maintenance work is required.

Do not use high-pressure cleaners.

In case of component failure due to abnormal circumstances or at end of life, replacement must be carried out by a suitably qualified and trained professional.

Warning: Do not open luminaire while mains supply is switched on.

Installation

The product must be installed and maintained by a suitably qualified professional in compliance with latest building/construction and/or electrical regulations and relevant legislation.

Warning: Switch off mains electrical supply prior to installing and connecting the luminaire.

Notice: If the luminaire is modified by anybody other than the original manufacturer, then the warranty will no longer be valid and shall become the full responsibility of the modifying person/organisation. Claims based on defects attributable to improper installation and/or application, and the consequences thereof, are excluded.

Attention: The luminaire is factory-sealed and does not need to be opened during installation.


The installation on site must comply with local and/or national health and safety regulations.


Installation Procedure

- 1) Switch off mains electrical supply.
- Check that rating shown on luminaire label conforms with mains electrical supply.
- Loosen pressure screw R and packing ring G.
 Place pressure screw R and packing ring G
 around mains cable C.
- Push at least 50 cm of mains cable C through spigot P. Reposition packing ring G and tighten pressure screw R to secure mains cable C.
- Loosen locking screws S to allow insertion of spigot P into spigot holder H. Keep support screw T tightened.
- Align and lock support screw T using spigot P keyway.
- into spigot holder **H**. Rotate luminaire counter-clockwise and allow it to rest on locating support screw **T**.

7) Push luminaire up until spigot **P** is fully recessed

- 8) Tighten locking screws **S**, to lock luminaire in position.
- Open luminaire by loosening screws L. Carefully unhook lanyard I.
- 10)Loosen screws J (do not turn out). Rotate gear tray M counter-clockwise and pull out gently.
- 11)Connect mains cable \boldsymbol{C} to terminal connector $\boldsymbol{K}.$
- 12) Return gear tray **M** to its original position and tighten screws **J**.
- 13) Reconnect lanyard I and close luminaire by tightening screws L.







WE-EF LEUCHTEN

Germany Tel +49 5194 909 0 Fax +49 5194 909 299 info.germany@we-ef.com

WE-EF LUMIERE

France
Tel +33 4 74 99 14 44
Fax +33 4 74 99 14 40
info.france@we-ef.com

WE-EF SWITZERLAND

Switzerland Tel +41 22 752 49 94 Fax +41 22 752 49 74 info.switzerland@we-ef.com

WE-EF LIGHTING

Thailand Tel +66 2 738 9610 Fax +66 2 175 2174 info.asiapacific@we-ef.com

WE-EF LIGHTING

Australia Tel +61 3 8587 0444 Fax +61 3 8587 0499 info.australia@we-ef.com

WE-EF LIGHTING

United States of America Tel +1 724 742 0030 Fax +1 724 742 0035 info.usa@we-ef.com

TO9201W0823 © WE-EF 2023

Technical specifications are subject to change.